

AM/FM MUSIC BOX

MB6000MAP
MB6000CHE

ENGLISH

GRUNDIG


Grundig Helpline: 1800 509 394

IMPORTANT SAFETY INSTRUCTIONS

Please note the following instructions when setting up the unit.

WARNING

To reduce the risk of electric shock, do not expose this unit to rain or moisture.



CAUTION

Using controls or otherwise adjusting the performance of this product than those specified in this manual may result in hazardous radiation exposure.

Read Instructions

Read all safety and operating instructions before operating the product.

Retain Instructions

Keep all safety and operating instructions for future reference.

Read Warnings

Take note of all warnings on the product and in the operating instructions.

Follow Instructions

Follow all operating and usage instructions.

Cleaning

Unplug this product from the power source before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.

Attachments

Do not use attachments or accessories not recommended as they may cause hazards.

Water and Moisture

Do not use this product near any water source or water hazard.

OVERVIEW



GRUNDIG MB6000 FM/AM Music Box

Thank you for purchasing your Grundig MB6000 AM/FM Music Box. In the following few paragraphs we will explain how to set up and use the MB6000.

POWER

Connect your radio using the supplied DC adaptor.

FUNCTIONS

OFF / FM / AM / AUX

Turn on your radio and select a radio band or auxiliary input. The POWER LED light will be on when you turn on your radio. Manually turn the tuning knob to tune a station. The VOLUME LED (Amber) light will be lit up when receiving a station.

VOLUME

Turn to adjust the volume.

FM ANTENNA

The MB6000 comes with two types of antenna for best FM reception. Select INTERNAL or EXTERNAL. For external, connect the supplied antenna to the EXTERNAL FM ANTENNA port and extend the antenna.

OVERVIEW

HEADPHONE JACK

Connect 3.5mm headphones (not supplied) to listen via headphones.

AUX IN

You can use the supplied stereo cable to connect your radio to other audio equipment.

OTHER INFORMATION

Specifications

Frequency Range	AM: 530 ~ 1710 KHZ FM: 87.5 ~ 108MHz
Speaker	Mono full-range, 3" driver unit
Frequency Response	80 Hz ~ 20 KHz
Dimension	210 mm X 132 mm X 132 mm (WHD)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

SERVICING

DO NOT attempt to service the unit yourself, as opening or removing the back panel may expose you to dangerous voltage and will void warranty.

Warranty

This product is warranted for any defect in materials or workmanship for one year after the original date of purchase. For warranty please contact our GRUNDIG HELPLINE: 1800 509 394. Have on hand your receipt of purchase.

PO Box 6287
Silverwater NSW 1811
www.grundig.net.au
GRUNDIG HELPLINE 1800 509 394